

ATMO®
TUBE

AIR

HEPA Air Purifier



USER MANUAL

Model: **AIR**

CONTENT

Safety Instructions	4
Getting To Know Your Air Purifier	6
Package Contents	
H13 Hepa Filter With 3-Stage Filtration	
Getting Started	7
Air Purifier Operation	8
Cleaning And Maintenance	9
Filter Replacement	10
Technical Specifications	11
Air Purifier Troubleshooting	11
Warranty	12

SAFETY INSTRUCTIONS



Failure to comply with the warnings listed below may result in electric shock or serious injury.

This air purifier is intended for private household use only and must be used in accordance with the usage instructions provided. Do not use it for purposes other than those indicated (private household air purification). Any other use is to be deemed improper and therefore dangerous.

- Read all instructions before using the device, and act in accordance with them. Keep this manual for future reference.
- In addition to the notes in the operating instructions, please take into consideration the general safety regulations and accident prevention guidelines applicable by law.
- Keep the packaging foil away from children as this poses a suffocation risk.

Hazard levels

DANGER

Indication of an imminent threat of danger that will lead to severe injuries or even death.

CAUTION

Indication of a potentially dangerous situation that may lead to minor injuries.

WARNING

Indication of a potentially dangerous situation that may lead to severe injuries or even death.

ATTENTION

Indication of a potentially dangerous situation that may lead to property damage.

General notes

DANGER

Check that the voltage at the outlet meets the technical specifications of the air purifier. If the mains supply is faulty, with frequent voltage drops or spikes, which may cause the electric or electronic components to catch fire, use a voltage stabilizer or other equipment to protect the device. Otherwise, there is a risk of damaging the device by overheating electrical circuits. Failure to do so may result in the cancellation of the warranty.

WARNING

- Persons with reduced physical, sensory, or mental capabilities and persons lacking experience and knowledge may only use the air purifier if they are properly supervised, have been instructed on the safe use of the device by a person responsible for their safety, and understand the resultant hazards involved.
- Children must be supervised to prevent them from playing with the device.
- Children must not play with the device.

SAFETY INSTRUCTIONS

Risk of electric shock

DANGER

- NEVER touch the plug or socket with wet hands.
- NEVER touch contacts or lines.
- To reduce the risk of fire or electrical shock, plug the air purifier directly into the correct AC electrical outlet.
- DO NOT attempt to repair or adjust any electrical or mechanical functions of this device. Doing so will void the warranty. There are no user-serviceable parts inside the device. All servicing should be performed by qualified personnel only.
- To reduce the risk of fire or electric shock, DO NOT use this device with any solid-state speed control device (such as a dimmer switch).

WARNING

- DO NOT use outdoors.
- DO NOT use in excessively humid areas.
- This air purifier has a polarized plug (one blade is wider than the other). To reduce the risk of electrical shock, the plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to override this safety feature.

Operation

DANGER

- To protect against electrical hazards, DO NOT immerse the air purifier in water or other liquids.
- DO NOT use in areas containing flammable gases, vapors, metallic dust, aerosol (spray) substances, or fumes emanating from industrial oils.

CAUTION

- DO NOT place anything on top of the air purifier.
- NEVER drop or insert any object into any device openings.
- DO NOT use the device if it has been dropped beforehand and is visibly damaged.
- DO NOT add essential oils to the device or filter. This will damage the filter and may create an unpleasant smell.
- DO NOT use oil diffusers near the device.


ATTENTION

NEVER block the air openings, grills/outlets, or place the air purifier on a soft surface such as a bed or sofa, as this could cause the device to tip over, blocking the air intake or outtake openings.

WARNING


- DO NOT use the air purifier without removing the plastic wrap from the filter. The device will not be able to filter air, and it may overheat, causing a fire hazard.
- DO NOT use near water.
- DO NOT route the power cord under carpeting.
- DO NOT cover the power cord with throw rugs, runners, or similar coverings.
- DO NOT route the power cord under furniture or appliances. Route the power cord away from foot traffic areas to reduce the risk of tripping.
- Always unplug the device before moving it, opening the grill, changing filters, cleaning, or whenever the device is not in use. Be sure to unplug the device by pulling on the plug; do not pull on the power cord.
To reduce the risk of fire, do not use near heat registers, radiators, stoves, or heaters.
- DO NOT operate the device if the power cord or plug is damaged, if the motor fan fails to rotate, if the device malfunctions, or if it has been dropped or damaged in any manner. Contact Customer Service for assistance.
- DO NOT use within five feet / 1.5 meters of areas where oxygen is being administered.

GETTING TO KNOW YOUR AIR PURIFIER



Package contents

- 1 x Air purifier
- 1 x Pre-installed H13 HEPA filter (wrapped in plastic that should be removed)
- 1 x Quick start guide
- 1 x User manual



H13 HEPA Filter with 3-stage filtration

- PRE-FILTER:** Retains large particles such as dust, lint, or animal hair.
- HEPA FILTER:** Retains dust microparticles (at least 99.97% of airborne particles 0.3 micrometers (µm) in diameter) such as pollen, mites, mold spores, bacteria, and viruses.
- ACTIVATED CARBON FILTER:** Reduces unpleasant odors such as cigarette smoke, food odors, and toxic gases.

GETTING STARTED



WARNING. DO NOT use the air purifier without removing the plastic wrap from the filter. The device will not be able to filter air, and it may overheat, causing a fire hazard. This may also lead to irreparable damage to the device and cancellation of the warranty.

1. Turn the air purifier over, and remove the filter cover cap by turning it counterclockwise.

(Image 1)

2. Remove the filter cover by lifting it.

(Image 2)

3. Pull the filter out from inside the device, remove the plastic wrapping, and re-insert the filter in the device.

(Image 3)


4. Put the filter cover back in place, and replace the filter cover cap by turning it clockwise to lock.

(Image 4)

5. Position the device on a level and secure surface, ensuring that the display is facing upward. Provide a minimum clearance of one foot / 30 centimeters around all sides of the device, and ensure there are no obstructions such as curtains that could impede airflow.

(Image 5)

6. Plug the power cord into the correct voltage AC outlet.

7. Press the “power button” 

to turn on the device.




Image 1




Image 2




Image 3




Image 4












































Image 5

AIR PURIFIER OPERATION

Power button		Turns the device on/ off.									
Fan speed button		Cycles through fan speeds:  (low),  (medium), and  (high)									
Sleep mode button		<p>Turns Sleep Mode on/ off. Sleep Mode operates quietly by using the lowest possible fan speed.</p> <ul style="list-style-type: none">• Tap the button to enter Sleep Mode. The indicator  will blink for 3 seconds. All indicators are off except the button • Tap the button again to turn off indicator.• Tap any key to exit Sleep Mode.									
Timer button		<p>You can set the time for 2, 4, 6, 8, 10, and 12 hours. Tap the button to select a time:</p> <table><tr><td>1 time – 2 hours ( indicator)</td><td>4 times – 8 hours ( indicator)</td><td>7 times – to cancel the timer (indicators are off)</td></tr><tr><td>2 times – 4 hours ( indicator)</td><td>5 times – 10 hours ( and  indicators)</td><td></td></tr><tr><td>3 times – 6 hours ( and  indicators)</td><td>6 times – 12 hours ( and  indicators)</td><td></td></tr></table> <p>The device will automatically turn off once the timer is finished.</p>	1 time – 2 hours ( indicator)	4 times – 8 hours ( indicator)	7 times – to cancel the timer (indicators are off)	2 times – 4 hours ( indicator)	5 times – 10 hours ( and  indicators)		3 times – 6 hours ( and  indicators)	6 times – 12 hours ( and  indicators)	
1 time – 2 hours ( indicator)	4 times – 8 hours ( indicator)	7 times – to cancel the timer (indicators are off)									
2 times – 4 hours ( indicator)	5 times – 10 hours ( and  indicators)										
3 times – 6 hours ( and  indicators)	6 times – 12 hours ( and  indicators)										
Night light and Dark mode button		<p>Turns the night light on with the first press. Dims the brightness to half with the second press. Turns the Dark Mode on with the third press – all lights are off.</p> <p>Tap any key to turn on the display light.</p>									
Filter change indicator/button		<p>Turns red to indicate that the filter needs to be replaced</p> <p>Press and hold the button for 3 – 5 seconds to turn off the red light after replacing the filter.</p>									
Child-lock mode button		<p>Press and hold the button for 3 – 5 seconds to turn on Child-lock Mode and disable the control panel.</p> <p>Press and hold the button again for 3 – 5 seconds to turn off Child-lock Mode and activate the control panel.</p>									



CLEANING AND MAINTENANCE




WARNING. Before cleaning, ensure that the air purifier is unplugged.





- Use a soft, dry cloth to gently wipe the exterior of the device. If needed, use a slightly dampened cloth, but be sure to promptly dry the surfaces.
- The filter should be cleaned once each month with a vacuum cleaner.
- The device interior should be cleaned once a month with a vacuum cleaner.
- Avoid cleaning the device with abrasive chemicals or flammable cleaning agents.
- Ensure that water does not enter the device. In case of accidental exposure to water, let the device dry completely before connecting it to power. If there is even the slightest possibility of water reaching the electronic circuits, please contact an authorized service center for a thorough inspection.

Filters should be replaced at least once every **six months**. More frequent cleaning and replacement may be required depending on environmental conditions.

FILTER REPLACEMENT

When the filter indicator turns red, it is time to replace the filter and reset the filter indicator.



1. Ensure that the air purifier is unplugged. (Image 1)
2. Flip over the air purifier, then turn the filter cover cap counterclockwise to detach it and set it aside. (Image 2)
3. Remove the filter cover from the purifier by lifting it. (Image 3)
4. Remove the old filter. (Image 4)
5. Take the new filter out of its plastic wrapping and insert it back into the purifier. (Image 5)
6. Put back the filter cover and twist the cover cap clockwise to lock. (Image 6)
7. Plug in the air purifier and turn it on. (Image 7)
8. Press and hold the “Filter change” button  for 3-5 seconds to turn off the red light. (Image 8)



TECHNICAL SPECIFICATIONS

Power Supply	120 V~, 60 Hz	Room Coverage	≤ 172 ft ² / 16 m ²
Operating Conditions	Temperature: 41°F ~ 104°F (5°C ~ 40°C) Humidity: < 85% RH	CADR	60 CFM (102 m ³ /h)
Rated Power	Night Mode: 7.5W ± 20% Speed I: 15W ± 20% Speed II: 21W ± 20% Speed III: 30W ± 20%	Dimensions	7.9 x 7.9 x 12.9 in (20 x 20 x 33 cm)
Standby Power	< 0.5W	Noise Level	Night Mode: < 28dB Speed I: < 36dB Speed II: < 43dB Speed III: < 48dB
		Weight	5.2 lb / 2.4 kg

TROUBLESHOOTING

PROBLEM	POSSIBLE SOLUTION
The air purifier does not start	<ul style="list-style-type: none">• Plug in the device, and press the “Power button” • Plug the device into a different outlet.• Check that the filter is securely installed.• Check if the power cord is damaged. If so, do not use the device, and contact Customer Support.
The device makes a loud/ disturbing noise	<ul style="list-style-type: none">• Check that the filter is properly in place with plastic packaging removed.• Check if foreign objects have come into contact with the fan.• Check if the filter is dirty/clogged and needs to be replaced.• Check that the bottom cover of the device is mounted correctly.• Check that the device is positioned correctly on a flat and hard surface.
Air flow is insufficient	<ul style="list-style-type: none">• Check that the filter is clean/ unclogged.• Check for obstacles that obstruct the air inlet and outlet grilles.• Tap the “Fan speed” button  to increase the fan speed.

WARRANTY

Atmotube 1-year Limited Warranty — the Limited Warranty extends only to the first consumer purchase of the product and is not transferable.

THE WARRANTY COVERS

With the Subject to the exclusions contained below, the company warrants the Atmotube and in-box accessories, accompanying the Product against defects in workmanship and material, under normal consumer use.

THE WARRANTY DOES NOT EXTEND TO THE FOLLOWING

- Natural wear/tear (scratches, alteration of the color and/or the materials of the device)
- Any damage to the device/its parts resulting from accident, misuse, liquid contact, fire, earthquake, or any other external cause, abnormal or abusive use, negligence or lack of care, or accidental damage (such as dents).
- Indirect damages of any kind.



The symbol on the air purifier or its packaging signifies that this device must be disposed of separately from ordinary household wastes at its end of life. Please kindly be aware that it is your responsibility to dispose of electronic equipment at recycling centers to help conserve natural resources.

Each country should have its collection centers for electrical/electronic equipment recycling. For detailed information about your recycling drop-off point, contact the retailer where you bought the device or your local recycling authority.

- Do not dispose of your device with household waste.
- Disposal of the packaging and your device should be done in accordance with local regulations.

For more information about Atmotube warranty and return policy, visit atmotube.com/warranty

© Atmotech Inc. All rights reserved.
Representative office address: 100 Pine
St. Suite 1250 San Francisco, CA 94111

